ExamKiller.net
World's NO.1 IT Certification Website

Exam Questions   **Online Test Engine**   **Study Guide**   **Audio Training**

CATEGORIES

Hot Vendor: Cisco Microsoft Oracle Avaya Altiris Apple IBM Nortel RSA Veritas Business Objects EMC Juniper

ExamKiller Inc.
Exam Questions Features

Based on the Real Exam Questions. Exhibits, Drag&Drop and Simulation Questions Included.

Study Guides are Constantly Updated To Reflect Current Exam Information!

Technical support available to answer your technical questions and queries.

Study Guides are provided in the universally accepted Adobe PDF format. No installation and no viruses. Easy to read and print.

Free 3 months Updates. No risk, 100% Money Back Guarantee.

Nortel 920-345

BCM 50/450 Rls.5.0 Installation & Initial Configuration

Practice Questions and Answers

By: ExamKiller Inc.

www.examkiller.net | support@examkiller.net

PLEASE READ:

ExamKiller's Industrious professionals have carefully designed and compiled this Practice Q&A for you. This Q&A aims at bringing the in-line ideas and concepts behind every question. It is better than other Practice Q&A because it's based in the Real Test Center. The answers to each question in this Q&A are not only exact and accurate but are verified as well. Some Q&A has explanations given in. They are written by the best people in industry enhancing your knowledge and learning experience. Instead of memorizing, our Q&A is made to make you understand things. You can read it a couple of times to increase your speed of exam attempt and comprehension.

All of our Q&As are updated regularly with changing exam objectives so keep an eye on the latest version of this Q&A to get the most updated and most accurate Q&A in line with the latest Exam objectives.

We welcome all your suggestions regarding this Q&A which can help us make this better for you. Please note down that the copy of this Q&A delivered by ExamKiller is only for your personal use and not for distribution. This Q&A is protected by US Copyright laws and any violation found may be dealt with legal action.

We thank you again for buying this Q&A product from us and we promise to continue serving you in future for all your Certification Training needs.

Promising your success,

ExamKiller

Technical Support Team

Session: 60 Questions

Untitled - Notepad

☐ Mark

Why do you need to set all the dipswitches on the right side to Off when installing the GATM4, GATM8, G4X16, or G8X16 media bay modules (MBM)?

○ A.   Off is their default position.

○ B.   These dipswitches are reserved for future functionality.

◉ C.   Allows the MBM to automatically download the country profile settings.

○ D.   Allows the MBM to automatically download the firmware settings.

Select the best answer.

| Next | | Item Review | | Comment | | Help |

Answer: C

Untitled - Notepad

☐ Mark

A customer is installing a GASM8 in a BCM450 in the North American region. They want to set the module to enhanced mode.

How must the Mode/Country DIP switches on the right side, at the rear of the module, be set?

○ A.   Set all DIP switches to On.

○ B.   Set all DIP switches to Off.

◉ C.   Set the first DIP switch to On and the rest (2-8) to Off.

○ D.   Set the first DIP switch to Off and the rest (2-8) to On.

Select the best answer.

| Next | Previous | Item Review | Comment | Help |

Answer: C

□ Mark   Time Remaining: 36:41

A customer is preparing to install a G4X16 module in a BCM450. They want the module to automatically download firmware upgrades. The country DIP switches (the right set of switches) must be confirmed they are in the correct position.

What must the customer ensure about the country DIP switches?

⊙ A.   that all of the country DIP switches are set to Off

○ B.   that all of the country DIP switches are set to On

○ C.   that the first country DIP switch is set to Off and the rest are set to On

○ D.   that the first two country DIP switches are set to On and the rest are set to Off

Select the best answer.

Next   Previous   Item Review   Comment   Help

Answer: A

Untitled - Notepad

You have installed a DSM32+ MBM in slot 1 of a new BCM450 main unit and you want to connect a set and perform set-based programming.

What is the next step?

○ A.   Configure the module.

○ B.   Identify the module.

○ C.   Deconfigure the module.

◉ D.   Connect a set to the DSM32+.

Select the best answer.

| Next | Previous | Item Review | Comment | Help |

Answer: D

Untitled - Notepad

You are installing a customer-supplied external non-trunk port paging system to a BCM450. It will provide paging over external loudspeakers.

What connections on the BCM450 will you be using?

○ A.   page output and ATA2

○ B.   page output and auxiliary power outlet

○ C.   speaker and page output

● D.   page output and page relay output

Select the best answer.

| Next | Previous | Item Review | Comment | Help |

Answer: D

Untitled - Notepad

Which is true of installing an uninterruptible power supply (UPS) that will be monitored by a BCM50 that is scheduled for backups to a USB thumb drive?

- ⦿ A.   You must use a USB hub between the UPS and the BCM50.

- ○ B.   You can connect the UPS whether or not the Business Communications Manager (BCM) is running.

- ○ C.   You must use a surge protector between the UPS and the AC power source.

- ○ D.   Use a small-system bracket to mount the UPS.

Select the best answer.

| Next | Previous | Item Review | Comment | Help |

Answer: A

Untitled - Notepad

☐ Mark

You are adding expansion units to a BCM50.

How do you power those units?

○ A.   Use the auxiliary power outlets on the main unit.

○ B.   An expansion unit power supply can support as many expansion units as you can add to the BCM.

○ C.   Upgrade the existing power supply to one that can support the main unit and all expansion units.

● D.   Each expansion unit must have a dedicated power supply.

Select the best answer.

| Next | Previous | Item Review | Comment | Help |

Answer: D

Untitled - Notepad

☐ Mark

Time Remaining: 35:58

A customer requires that a BCM50 be wall mounted. There are two expansion units as well as the main unit.

Which equipment is required to perform this installation?

○ A.   One wallmount shelf and one wiring field card.

○ B.   One Small System Wallmount Bracket to hold the two expansion units and one Small System Wallmount Shelf for the main unit.

⊙ C.   Three Small System Wallmount Brackets or one Small System Wallmount Shelf.

○ D.   One wallmount shelf and two wiring field cards.

Select the best answer.

Next   Previous   Item Review   Comment   Help

Answer: C

Untitled - Notepad

You want to install a Digital Trunk Module (DTM) in the BCM450 main unit.

How must you set the DIP switches on the DTM?

- ⦿ A.   Set all of the DIP switches to On.
- ○ B.   Set all of the DIP switches to Off.
- ○ C.   Set the first DIP switch to On and set the rest (2-6) to Off.
- ○ D.   Set the first DIP switch to Off and set the rest (2-6) to On.

Select the best answer.

| Next | Previous | Item Review | Comment | Help |

Answer: A

Untitled - Notepad

Time Remaining: 35:42

You are installing a BCM50 at a small business site with seven digital stations. The customer wants to connect two PCs directly to the BCM50 to share an internet connection. The Internet access is provided via an Ethernet connection.

Which hardware configuration can support this installation?

○ A.   BCM expansion unit

○ B.   BCM50 main unit

○ C.   BCM50a main unit

○ D.   BCM50b main unit

● E.   BCM50e main unit

Select the best answer.

| Next | | Previous | | Item Review | | Comment | | Help |

Answer: E

You passed the test with a score of 100%. A minimum of 70% is required.

C O N G R A T U L A T I O N S !

Section Scores for ☑ Untitled - Notepad ▬ ☐ ☒ ☒

Section Analysis	Percent Correct
BCM50/450 Components	100 %
BCM50/450 Installation	100 %
BCM50 Configuration	100 %
Unified Communication features	100 %
BCM50 - CallPilot Setup	100 %

OK   Comment   Help